



VEPRO OY

Fitting instructions for 3038 FORD TRANSIT CONNECT 2014-

1. Place the sun visor on the door pillar. Measure the correct height as shown on the picture (495mm +/-10mm depending on driver height) and mark the hole positions.
2. Drill the holes with 4,0mm bit. Clean the drilled area and put some Sikaflex 221 or 252 or similar on and around the drilled holes.
3. Fit the visor on the door pillars. Adjust the visors angle and tighten all screws.
4. Fit the nut cover hats and cover collar hats.
5. Mount the warning label on a place where the driver can see it.

Remember to tighten all screws after few hours drive and every 6 months.

WARNING!

The speed limit for the vehicle with the visor mounted is 130 km/h.
If you drive constantly faster than 130 km/h the visor may tear off!

**ANY NON-COMPLIANCE WITH THESE REGULATIONS CAUSE NO
RESPONSIBILITY TO THE MANUFACTURER OF ANY COSTS AND DAMAGES.**



Osoite/Address
Tehtaankatu 21
11710 RIIHIMÄKI
FINLAND

Puhelin/Telephone
+ 358 19 724 000

Telefax
+ 358 19 720 765

Pankki/Bank
OKO 539602-254945
Sampo 800016-70104554
FI09001798