

ARB **RECOVERY**

E-Z DEFLATOR – FOR RAPID TYRE DEFLATION

THE ORIGINAL AND BEST – PROUDLY DESIGNED IN THE USA
SUITABLE FOR PART NUMBER - ARB505/600/510

INSTRUCTIONS



1. With the slide valve pushed forward, thread the valve stem adaptor onto the valve stem in a clockwise direction.



2. Push the valve core remover forward until it engages the valve and turn anti-clockwise to remove valve.



3. When the valve core is removed it will push the core remover out and the gauge will read the tyre pressure.



4. Pull out on the slide valve to release air. Push in on the slide valve to stop air and check the pressure. Note, gauge will not show correct pressure whilst deflating.



5. When the desired pressure is reached, push the valve core remover in and turn clockwise until the valve seats firmly.

Note: Do not over tighten the valve core.



6. Remove the unit by turning the valve stem adaptor in an anti-clockwise direction. Ensure a valve cap is placed on the valve stem to prevent ingress of debris.

This tyre gauge has a full geared, solid brass precision movement with bronze bourdon tube. Unlike piston-plunger-type gauges, the bourdon tube movement is not affected by changes in temperature, humidity or altitude.

The gauge has been tested for accuracy before shipment.

WARNING: To avoid the possibility of eye injury, eye protection should be worn when using this gauge or when attempting any tyre repairs.

Digital Deflator

The digital deflator works the same as the Analogue deflator just using a Digital gauge for improved accuracy and easier read outs.

Functions & Use.

The digital gauge should wake up when pressure is applied to the gauge, if the gauge dose not wake up press the on button once to turn on the gauge.

The Function button allows you to scroll through the different measurements, pressing the function button once will move to the next pressure measurement, keep pressing the button to move to desired pressure setting. Note do not press and hold any of the buttons down for extended periods.

The gauge will only show pressure when the pressure is static, during deflating the gauge will not show a pressure, this is the normal operation of this device.



Conversion Table

PSI	KPA (approx)
5	34.5
10	69
15	103.5
20	138
25	172.5
30	207
35	241.5
40	276
45	310.5
50	345
55	379
60	413.5

ARB Corporation Ltd
42-44 Garden Street
Kilsyth VIC 3137
Australia
www.arb.com.au

E-Z Deflator is a Trademark of Burkey Manufacturing
Patent #5,665,908

Proudly Designed in the United States of America

Tested and assembled in China from components manufactured in China for ARB

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. If this product requires warranty, please return to your closest ARB store accompanied with your receipt of purchase. Warranty period of 2 years from Date of purchase applies to this product

SLIDE VALVE FORWARD
TO HOLD/READ
PRESSURE BACK TO
BLEED AIR

VALVE STEM ADAPTOR
HANDLE. SCREWS UNIT
ONTO VALVE STEM

VALVE CORE HANDLE.
SCREW CLOCKWISE TO
INSERT VALVE, ANTI-
CLOCKWISE TO REMOVE
VALVE

INTERNAL THREAD
ADAPTS TO VALVE
STEM

